

PANMOBIL SCANNDY2 Configuration Codes



Start configuration mode



USB HID



USB mass storage



USB serial



USB Ethernet



Copy config



Reset to defaults



HID layout DE



HID layout US



HID layout FR



HID layout Alt-Keypad (generic)



End configuration mode

